

	<b>SONARtrac<sup>®</sup> Technical Note</b>	
	<b>TN0015</b>	
	<b>Subject: Use of Band Clamps on 2" – 8" Fiberglass Covers</b>	
		Date: 07Nov08
		Revision   02
		Page 1 of 1

The use of a band clamp, typically used on fiberglass cover sizes 10" and above, is an acceptable alternative to the Clampco tee-bolt clamp. When properly installed per the SONARtrac Installation Manual, the band clamp is equivalent to the Clampco tee-bolt clamp.

The use of a BAND-IT<sup>®</sup> Model C00169 Banding Tool (or equivalent) is necessary. The tool is available as our P/N 52511-01; contact Customer Support for ordering information. This tool is also available in the United States from McMaster Carr Company (telephone 630-833-0300, internet [www.mcmaster.com](http://www.mcmaster.com)) as their P/N 5424K1. Other suppliers are available worldwide. Contact BAND-IT at 800-525-0758 or 303-320-4555 or [www.band-it-idex.com](http://www.band-it-idex.com).

Full instructions for the installation of the band clamps are found in Sensor Installation Chapter of the SONARtrac Installation Manual.

Contact CiDRA Technical Support or Customer Support with any questions.

### Revision History

Rev	Date	Changed By	Approved By	Change Description
01	07Nov08	Markoja	Markoja	Initial Release
02	11Nov08	Markoja	Markoja	Reword

CiDRA Corporate Services	50 Barnes Park North	Wallingford, CT 06492
Tel. 203-265-0035	Fax. 203-294-4211	<a href="http://www.cidra.com">www.cidra.com</a>